

§ 250.604 Hydrogen sulfide.

When a well-workover operation is conducted in zones known to contain hydrogen sulfide (H₂S) or in zones where the presence of H₂S is unknown (as defined in § 250.417 of this part), the lessee shall take appropriate precautions to protect life and property on the platform or rig, including but not limited to operations such as blowing the well down, dismantling wellhead equipment and flow lines, circulating the well, swabbing, and pulling tubing, pumps and packers. The lessee shall comply with the requirements in § 250.417 of this part as well as the appropriate requirements of this subpart.

[53 FR 10690, Apr. 1, 1988. Redesignated and amended at 63 FR 29479, 29485, May 29, 1998; 64 FR 9065, Feb. 24, 1999]

§ 250.605 Subsea workovers.

No subsea well-workover operation including routine operations shall be commenced until the lessee obtains written approval from the District Supervisor in accordance with § 250.613 of this part. That approval shall be based upon a case-by-case determination that the proposed equipment and procedures will maintain adequate control of the well and permit continued safe production operations.

[53 FR 10690, Apr. 1, 1988. Redesignated and amended at 63 FR 29479, 29485, May 29, 1998]

§ 250.606 Crew instructions.

Prior to engaging in well-workover operations, crew members shall be instructed in the safety requirements of the operations to be performed, possible hazards to be encountered, and general safety considerations to protect personnel, equipment, and the environment. Date and time of safety meetings shall be recorded and available at the facility for review by a Minerals Management Service representative.

§§ 250.607–250.608 [Reserved]**§ 250.609 Well-workover structures on fixed platforms.**

Derricks, masts, substructures, and related equipment shall be selected, designed, installed, used, and maintained so as to be adequate for the potential

loads and conditions of loading that may be encountered during the operations proposed. Prior to moving a well-workover rig or well-servicing equipment onto a platform, the lessee shall determine the structural capability of the platform to safely support the equipment and proposed operations, taking into consideration the corrosion protection, age of the platform, and previous stresses to the platform.

§ 250.610 Diesel engine air intakes.

No later than May 31, 1989, diesel engine air intakes shall be equipped with a device to shut down the diesel engine in the event of runaway. Diesel engines which are continuously attended shall be equipped with either remote operated manual or automatic shutdown devices. Diesel engines which are not continuously attended shall be equipped with automatic shutdown devices.

[53 FR 10690, Apr. 1, 1988, as amended at 54 FR 50616, Dec. 8, 1989. Redesignated at 63 FR 29479, May 29, 1998]

§ 250.611 Traveling-block safety device.

After May 31, 1989, all units being used for well-workover operations which have both a traveling block and a crown block shall be equipped with a safety device which is designed to prevent the traveling block from striking the crown block. The device shall be checked for proper operation weekly and after each drill-line slipping operation. The results of the operational check shall be entered in the operations log.

§ 250.612 Field well-workover rules.

When geological and engineering information available in a field enables the District Supervisor to determine specific operating requirements, field well-workover rules may be established on the District Supervisor's initiative or in response to a request from a lessee. Such rules may modify the specific requirements of this subpart. After field well-workover rules have been established, well-workover operations in the field shall be conducted in accordance with such rules and other requirements of this subpart. Field well-